

Wallpaper Installation

WALL TO WALL APPLICATION

1. Unroll the first panel on a clean floor, with the pattern facing down.
2. Starting at the top, peel back the first six inches of the backing paper and fold it onto itself.
3. Align the top of your panel with the top of the wall, starting from the left. Allow the adhesive to extend one inch onto the ceiling across the full width, in case the ceiling is not perfectly straight. It is important to mark your 1/2 inch reference points with a pencil at the top and along the side of your panel.
4. Make sure the right vertical edge of your panel is level, so the following panels will align properly as well.
5. Adhere the top section using your plastic squeegee, making long horizontal strokes from the center outward. Smooth to push any air bubbles toward the edges. Peel away an additional 12 inches of backing paper. It is important to pull the backing straight and with both hands. Avoid squeegeeing over the area where the backing paper is folded.
6. Repeat the same squeegee movements, from the center toward the edges, until the panel is fully adhered to the wall.
7. Continue these steps down to the bottom of the wall, taking your time.
8. Take a new panel and, at the top, fold back the first six inches of the backing paper as described in step one.
9. Position the second panel along the pencil marks, making sure the patterns align properly. If adjustments are needed, our removable material allows the panel to be peeled off and repositioned. Do not hesitate to readjust. The panels are designed to overlap by 1/2 inch. Mark small reference points on the panel already on the wall with a pencil at 1/2 inch. Then adhere the top of the second panel and repeat the previous steps until the entire surface is covered.
10. Use your squeegee to firmly press the corners where excess vinyl needs to be trimmed, such as at the ceiling, floor, or along the right wall.

Corner preparation :

- When working with corners using peel and stick wallpaper, measure the distance from your last panel to the corner at several heights to account for uneven walls. Cut the next panel slightly wider to ensure full coverage.
- Slightly overlap the wallpaper into the corner, smooth it firmly, and fold it onto the adjacent wall without creating creases.
- Trim any excess material for a clean finish. This method helps maintain a seamless look and ensures the pattern continues smoothly around the corner.

N'hésitez pas si vous avez des questions avant ou pendant l'installation, n'hésitez pas à nous contacter.
Nous sommes là pour vous aider. Contactez-nous à info@artza.ca.