

Wallpaper Installation

APPLICATION ON AN ACCENT WALL

1. Unroll the first panel on a clean floor, with the pattern facing down.
2. Starting at the top, peel back the first six inches of the backing paper and fold it onto itself.
3. Align the top of your panel with the top of the wall, starting from the left. Let the adhesive extend one inch past the ceiling across the full width, in case the ceiling is not perfectly straight. It is important to mark your ½ inch reference points with a pencil at the top and along the side of the panel.
4. Make sure the right vertical edge of your panel is level so that the following panels will also be straight.
5. Adhere the top section using a plastic squeegee, making long horizontal strokes from the center outward. Push any air bubbles toward the edges. Peel back an additional 12 inches of backing paper. It is important to pull the paper straight and use both hands. Avoid squeegeeing over the area where the backing paper is folded.
6. Repeat the same squeegee motions, from the center toward the edges, until the panel is fully adhered to the wall.
7. Continue these steps down to the bottom of the wall, taking your time.
8. Take a new panel and fold back the first six inches of the backing paper at the top, as mentioned in step one.
9. Position the second panel along the pencil marks, making sure the patterns align properly. If you need to adjust the pattern match, our removable material allows you to peel and reposition the panel. Do not hesitate to readjust. The panels are designed to overlap by ½ inch. Mark small reference points on the panel already installed on the wall using a pencil at the ½ inch overlap. Adhere the top of the second panel and repeat the previous steps until the entire surface is covered.
10. Use your squeegee to firmly press into the corners where excess vinyl needs to be trimmed, such as at the ceiling, floor, or right wall.